


# VYTYČOVACÍ VÝKRES - PILIERE 2P-6P



SÚRADNICE PILIER 2P				
BOD	Súradnice			Poznámka
	Y [m]	X [m]	Z [m.n.m.]	
205-PR-2P-01	438084,458	1146963,434	426,898	pilier - dolná hrana
	438084,458	1146963,434	436,950	pilier - horná hrana
205-PR-2P-02	438084,967	1146962,023	426,898	pilier - dolná hrana
	438084,967	1146962,023	436,950	pilier - horná hrana
205-PR-2P-03	438085,415	1146961,813	426,873	pilier - dolná hrana
	438085,415	1146961,813	436,950	pilier - horná hrana
205-PR-2P-04	438086,167	1146962,084	426,873	pilier - dolná hrana
	438086,167	1146962,084	436,950	pilier - horná hrana
205-PR-2P-05	438086,378	1146962,532	426,898	pilier - dolná hrana
	438086,378	1146962,532	436,950	pilier - horná hrana
205-PR-2P-06	438085,869	1146963,943	426,898	pilier - dolná hrana
	438085,869	1146963,943	436,950	pilier - horná hrana
205-PR-2P-07	438085,421	1146964,154	426,873	pilier - dolná hrana
	438085,421	1146964,154	436,950	pilier - horná hrana
205-PR-2P-08	438084,669	1146963,883	426,873	pilier - dolná hrana
	438084,669	1146963,883	436,950	pilier - horná hrana
205-PR-2P-09	438090,196	1146965,504	426,898	pilier - dolná hrana
	438090,196	1146965,504	436,790	pilier - horná hrana
205-PR-2P-10	438090,705	1146964,093	426,898	pilier - dolná hrana
	438090,705	1146964,093	436,790	pilier - horná hrana
205-PR-2P-11	438091,153	1146963,883	426,873	pilier - dolná hrana
	438091,153	1146963,883	436,790	pilier - horná hrana
205-PR-2P-12	438091,905	1146964,154	426,873	pilier - dolná hrana
	438091,905	1146964,154	436,790	pilier - horná hrana
205-PR-2P-13	438092,116	1146964,602	426,898	pilier - dolná hrana
	438092,116	1146964,602	436,790	pilier - horná hrana
205-PR-2P-14	438091,607	1146966,013	426,898	pilier - dolná hrana
	438091,607	1146966,013	436,790	pilier - horná hrana
205-PR-2P-15	438091,159	1146966,223	426,873	pilier - dolná hrana
	438091,159	1146966,223	436,790	pilier - horná hrana
205-PR-2P-16	438090,407	1146965,952	426,873	pilier - dolná hrana
	438090,407	1146965,952	436,790	pilier - horná hrana
205-PR-2P-17	438088,299	1146964,023	-	priesečník osí

SÚRADNICE PILIER 3P				
BOD	Súradnice			Poznámka
	Y [m]	X [m]	Z [m.n.m.]	
205-PR-3P-01	438098,133	1146925,829	425,428	pilier - dolná hrana
	438098,133	1146925,829	436,480	pilier - horná hrana
205-PR-3P-02	438098,648	1146924,420	425,428	pilier - dolná hrana
	438098,648	1146924,420	436,480	pilier - horná hrana
205-PR-3P-03	438099,097	1146924,212	425,403	pilier - dolná hrana
	438099,097	1146924,212	436,480	pilier - horná hrana
205-PR-3P-04	438099,848	1146924,486	425,403	pilier - dolná hrana
	438099,848	1146924,486	436,480	pilier - horná hrana
205-PR-3P-05	438100,057	1146924,935	425,428	pilier - dolná hrana
	438100,057	1146924,935	436,480	pilier - horná hrana
205-PR-3P-06	438099,542	1146926,344	425,428	pilier - dolná hrana
	438099,542	1146926,344	436,480	pilier - horná hrana
205-PR-3P-07	438099,093	1146926,552	425,403	pilier - dolná hrana
	438099,093	1146926,552	436,480	pilier - horná hrana
205-PR-3P-08	438098,342	1146926,278	425,403	pilier - dolná hrana
	438098,342	1146926,278	436,480	pilier - horná hrana
205-PR-3P-09	438103,864	1146927,921	425,428	pilier - dolná hrana
	438103,864	1146927,921	436,480	pilier - horná hrana
205-PR-3P-10	438104,378	1146926,512	425,428	pilier - dolná hrana
	438104,378	1146926,512	436,480	pilier - horná hrana
205-PR-3P-11	438113,129	1146926,303	425,403	pilier - dolná hrana
	438113,129	1146926,303	436,480	pilier - horná hrana
205-PR-3P-12	438105,578	1146926,577	425,403	pilier - dolná hrana
	438105,578	1146926,577	436,480	pilier - horná hrana
205-PR-3P-13	438105,787	1146927,026	425,428	pilier - dolná hrana
	438105,787	1146927,026	436,480	pilier - horná hrana
205-PR-3P-14	438105,273	1146928,435	425,428	pilier - dolná hrana
	438105,273	1146928,435	436,480	pilier - horná hrana
205-PR-3P-15	438104,824	1146928,644	425,403	pilier - dolná hrana
	438104,824	1146928,644	436,480	pilier - horná hrana
205-PR-3P-16	438104,073	1146928,370	425,403	pilier - dolná hrana
	438104,073	1146928,370	436,480	pilier - horná hrana
205-PR-3P-17	438101,960	1146926,428	-	priesečník osí

SÚRADNICE PILIER 4P				
BOD	Súradnice			Poznámka
	Y [m]	X [m]	Z [m.n.m.]	
205-PR-4P-01	438111,703	1146888,244	425,098	pilier - dolná hrana
	438111,703	1146888,244	435,960	pilier - horná hrana
205-PR-4P-02	438112,203	1146886,829	425,098	pilier - dolná hrana
	438112,203	1146886,829	435,960	pilier - horná hrana
205-PR-4P-03	438112,650	1146886,616	425,073	pilier - dolná hrana
	438112,650	1146886,616	435,960	pilier - horná hrana
205-PR-4P-04	438113,404	1146886,882	425,073	pilier - dolná hrana
	438113,404	1146886,882	435,960	pilier - horná hrana
205-PR-4P-05	438113,617	1146887,329	425,098	pilier - dolná hrana
	438113,617	1146887,329	435,960	pilier - horná hrana
205-PR-4P-06	438113,118	1146888,743	425,098	pilier - dolná hrana
	438113,118	1146888,743	435,960	pilier - horná hrana
205-PR-4P-07	438112,671	1146888,957	425,073	pilier - dolná hrana
	438112,671	1146888,957	435,960	pilier - horná hrana
205-PR-4P-08	438111,917	1146888,691	425,073	pilier - dolná hrana
	438111,917	1146888,691	435,960	pilier - horná hrana
205-PR-4P-09	438117,455	1146890,276	425,098	pilier - dolná hrana
	438117,455	1146890,276	436,150	pilier - horná hrana
205-PR-4P-10	438117,955	1146888,861	425,098	pilier - dolná hrana
	438117,955	1146888,861	436,150	pilier - horná hrana
205-PR-4P-11	438118,402	1146888,648	425,073	pilier - dolná hrana
	438118,402	1146888,648	436,150	pilier - horná hrana
205-PR-4P-12	438119,155	1146888,914	425,073	pilier - dolná hrana
	438119,155	1146888,914	436,150	pilier - horná hrana
205-PR-4P-13	438119,369	1146889,361	425,098	pilier - dolná hrana
	438119,369	1146889,361	436,150	pilier - horná hrana
205-PR-4P-14	438118,869	1146890,775	425,098	pilier - dolná hrana
	438118,869	1146890,775	436,150	pilier - horná hrana
205-PR-4P-15	438118,423	1146890,989	425,073	pilier - dolná hrana
	438118,423	1146890,989	436,150	pilier - horná hrana
205-PR-4P-16	438117,669	1146890,722	425,073	pilier - dolná hrana
	438117,669	1146890,722	436,150	pilier - horná hrana
205-PR-4P-17	438115,548	1146888,807	-	priesečník osí

SÚRADNICE PILIER 5P				
BOD	Súradnice			Poznámka
	Y [m]	X [m]	Z [m.n.m.]	
205-PR-5P-01	438124,532	1146850,472	423,728	pilier - dolná hrana
	438124,532	1146850,472	435,590	pilier - horná hrana
205-PR-5P-02	438124,991	1146849,044	423,728	pilier - dolná hrana
	438124,991	1146849,044	435,590	pilier - horná hrana
205-PR-5P-03	438125,432	1146848,818	423,703	pilier - dolná hrana
	438125,432	1146848,818	435,590	pilier - horná hrana
205-PR-5P-04	438126,193	1146849,063	423,703	pilier - dolná hrana
	438126,193	1146849,063	435,590	pilier - horná hrana
205-PR-5P-05	438126,419	1146849,503	423,728	pilier - dolná hrana
	438126,419	1146849,503	435,590	pilier - horná hrana
205-PR-5P-06	438125,960	1146850,931	423,728	pilier - dolná hrana
	438125,960	1146850,931	435,590	pilier - horná hrana
205-PR-5P-07	438125,519	1146851,157	423,703	pilier - dolná hrana
	438125,519	1146851,157	435,590	pilier - horná hrana
205-PR-5P-08	438124,758	1146850,913	423,703	pilier - dolná hrana
	438124,758	1146850,913	435,590	pilier - horná hrana
205-PR-5P-09	438130,339	1146852,340	423,728	pilier - dolná hrana
	438130,339	1146852,340	435,780	pilier - horná hrana
205-PR-5P-10	438130,798	1146850,912	423,728	pilier - dolná hrana
	438130,798	1146850,912	435,780	pilier - horná hrana
205-PR-5P-11	438131,239	1146850,686	423,703	pilier - dolná hrana
	438131,239	1146850,686	435,780	pilier - horná hrana
205-PR-5P-12	438132,000	1146850,931	423,703	pilier - dolná hrana
	438132,000	1146850,931	435,780	pilier - horná hrana
205-PR-5P-13	438132,226	1146851,371	423,728	pilier - dolná hrana
	438132,226	1146851,371	435,780	pilier - horná hrana
205-PR-5P-14	438131,767	1146852,799	423,728	pilier - dolná hrana
	438131,767	1146852,799	435,780	pilier - horná hrana
205-PR-5P-15	438131,326	1146853,025	423,703	pilier - dolná hrana
	438131,326	1146853,025	435,780	pilier - horná hrana
205-PR-5P-16	438130,565	1146852,780	423,703	pilier - dolná hrana
	438130,565	1146852,780	435,780	pilier - horná hrana
205-PR-5P-17	438128,379	1146850,922	-	priesečník osí

SÚRADNICE PILIER 6P				
BOD	Súradnice			Poznámka
	Y [m]	X [m]	Z [m,n.m.]	
205-PR-6P-01	438135,930	1146812,317	424,348	pilier - dolná hrana
	438135,930	1146812,317	435,210	pilier - horná hrana
205-PR-6P-02	438136,322	1146810,870	424,348	pilier - dolná hrana
	438136,322	1146810,870	435,210	pilier - horná hrana
205-PR-6P-03	438136,752	1146810,624	424,323	pilier - dolná hrana
	438136,752	1146810,624	435,210	pilier - horná hrana
205-PR-6P-04	438137,524	1146810,833	424,323	pilier - dolná hrana
	438137,524	1146810,833	435,210	pilier - horná hrana
205-PR-6P-05	438137,770	1146811,263	424,348	pilier - dolná hrana
	438137,770	1146811,263	435,210	pilier - horná hrana
205-PR-6P-06	438137,377	1146812,710	424,348	pilier - dolná hrana
	438137,377	1146812,710	435,210	pilier - horná hrana
205-PR-6P-07	438136,948	1146812,956	424,323	pilier - dolná hrana
	438136,948	1146812,956	435,210	pilier - horná hrana
205-PR-6P-08	438136,176	1146812,747	424,323	pilier - dolná hrana
	438136,176	1146812,747	435,210	pilier - horná hrana
205-PR-6P-09	438141,817	1146813,915	424,348	pilier - dolná hrana
	438141,817	1146813,915	435,400	pilier - horná hrana
205-PR-6P-10	438142,210	1146812,467	424,348	pilier - dolná hrana
	438142,210	1146812,467	435,400	pilier - horná hrana
205-PR-6P-11	438142,639	1146812,221	424,323	pilier - dolná hrana
	438142,639	1146812,221	435,400	pilier - horná hrana
205-PR-6P-12	438143,411	1146812,430	424,323	pilier - dolná hrana
	438143,411	1146812,430	435,400	pilier - horná hrana
205-PR-6P-13	438143,657	1146812,860	424,348	pilier - dolná hrana
	438143,657	1146812,860	435,400	pilier - horná hrana
205-PR-6P-14	438143,265	1146814,307	424,348	pilier - dolná hrana
	438143,265	1146814,307	435,400	pilier - horná hrana
205-PR-6P-15	438142,835	1146814,553	424,323	pilier - dolná hrana
	438142,835	1146814,553	435,400	pilier - horná hrana
205-PR-6P-16	438142,063	1146814,344	424,323	pilier - dolná hrana
	438142,063	1146814,344	435,400	pilier - horná hrana
205-PR-6P-17	438139,806	1146812,592	-	preseknosi osi